















# sofaforma

## ASSEMBLY INSTRUCTIONS

### FOR HARPER



AX16 M8*30 	BX30 M8*40 	CX4 M4*25 	DX30 M8 	EX16 M8 
FX20 M8 	GX1 	HX1 	IX1 	JX1 
KX4 	LX4 	MX4 	NX1 